

Eutech DO 450



Dissolved Oxygen / Temperature

Affordable optical RDO technology reduces maintenance time and costs

- Maintenance free optical probe with no electrolyte eliminates hassle of replacing delicate membranes and salt build up from refilling solutions
- Durable waterproof and dustproof design with IP67 rating
- Large, backlit custom display provides measurement with temperature
- Switch between % saturation and mg/L (ppm) dissolved oxygen with a press of a button
- **Calibration due alarm** – Set a visible reminder when it is time to recalibrate the meter
- Manual barometric pressure and salinity correction
- **Selectable °C or °F** – Choose the unit to best fit your application
- Ready indicator, manual or automatic measurement hold feature and optional automatic shutoff function
- **Store up to 500 data sets** – Easy USB or RS232 output with optional data cables
- **Built-in real-time clock stamps stored data and calibration data with time and date** – Meets standards for GLP (Good Laboratory Practices)
- 500 hours battery life or use optional universal power adapter
- **Built-in stand with wall-mount** – Allows for easy benchtop measurement and storage



Calibration Chamber



RDO Weight/Guard



RDO Sensor Cap



RDO Probe



Specification Table

Dissolved Oxygen	Range	0 to 200 %; 0 to 20 ppm/mg/L
	Resolution	0.10 %; 0.1 ppm/mg/L
	Accuracy	±2 %; ±0.1 ppm or mg/L up to 8; ±0.2 ppm or mg/L above 8
	Calibration	Zero and saturation
Temperature	Range	0.0 to 50.0 °C (0.0 to 122.0 °F)
	Resolution	0.1 °C/°F
	Accuracy	±0.5 °C; ±0.9 °F
	Calibration	Offset in 0.1 increments, ±10 °C or ±18 °F
Display	Custom LCD with backlight	
Memory	Stores up to 500 data sets	
Output	USB or RS232	
Real-Time Clock	Time and date stamp on calibration and stored data	
Temperature Compensation	Yes	
Pressure & Salinity Compensation	Manual	
Power	Two AA batteries (included), >100 hours (without backlight); AC adapter (optional)	



Ordering Information

Order Code	Part No.	Description
Meter		
ECDOWP45000	01X651634	DO 450 Meter Only: Meter, two AA batteries
ECDOWP45003	01X651644	DO 450 Meter & Electrode: Meter, RDO electrode with sensor cap, two AA batteries
ECDOWP45003K	01X651635	DO 450 Meter Kit: Meter, RDO electrode with sensor cap, two AA batteries, hard carry case, USB cable, RDO stainless steel weight/guard, RDO calibration chamber
Electrodes		
RDO3M	RDO3M	RDO probe, 3 m (10 ft) cable
RDO6M	RDO6M	RDO probe, 6 m (20 ft) cable
RDO15M	RDO15M	RDO probe, 15 m (50 ft) cable
Accessories		
RDOCAP	RDOCAP	Replacement RDO sensor cap
RDOWEIGHT	RDOWEIGHT	RDO weight/guard, screw thread to attach to probe
RDOCALCHAMBER	RDOCALCHAMBER	Calibration chamber
60X426401	60X426401	Optional 100 / 240 VAC SMPS power adapter, 9V, 6W
MINIPHONEUSB	MINIPHONEUSB	USB cable for 450 series, mini phone plug to USB
30X427301	30X427301	RS232 cable for 450 series, mini phone plug to RS232 9-pin (F)
ECDOZEROSOLN	01X211238	Zero oxygen solution, 0 % DO, 480 mL